

Dell™ OptiPlex™ FX160

Setup and Quick Reference Guide

This guide provides an overview of features, specifications, quick setup, software, and troubleshooting information for your computer. For more information about your operating system, devices, and technologies, see the *Dell Technology Guide* at support.dell.com.

Model DC01T

Notes, Notices, and Cautions



NOTE: A NOTE indicates important information that helps you make better use of your computer.



NOTICE: A NOTICE indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.



CAUTION: A CAUTION indicates a potential for property damage, personal injury, or death.

If you purchased a Dell™ n Series computer, any references in this document to Microsoft® Windows® operating systems are not applicable.

Macrovision Product Notice

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Information in this document is subject to change without notice.

© 2008 Dell Inc. All rights reserved.

Reproduction of these materials in any manner whatsoever without the written permission of Dell Inc. is strictly forbidden.

Trademarks used in this text: *Dell*, the *DELL* logo, *OptiPlex*, and *DellConnect* are trademarks of Dell Inc.; *Bluetooth* is a registered trademark owned by Bluetooth SIG, Inc., and is used by Dell under license; *Intel* and *Atom* are registered trademarks of Intel Corporation in the U.S. and other countries; *Microsoft*, *Windows*, *Windows Vista*, and the *Windows Vista* start button are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Other trademarks and trade names may be used in this document to refer to either the entities claiming the marks and names or their products. Dell Inc. disclaims any proprietary interest in trademarks and trade names other than its own.

Model DC01T

August 2008

P/N C742D

Rev. A00


Contents

- 1 About Your Computer 5
 - Front View 5
 - Back View 6
- 2 Setting Up Your Computer 7
 - Before Setting Up Your Computer 7
 - Quick Setup 7
- 3 Specifications 11
- 4 Troubleshooting Tips 17
 - Using the Hardware Troubleshooter 17
 - Tips 17
 - Power Problems 17
 - Memory Problems 18
 - Lockups and Software Problems 19
 - Dell Technical Update Service 20
 - Dell Support Utility 20
 - Dell Diagnostics 21

5	Reinstalling Software	23
	Drivers	23
	Identifying Drivers	23
	Reinstalling Drivers and Utilities	24
	Restoring Your Operating System	26
	Using Microsoft Windows System Restore (Windows Vista hard drive operating systems only)	26
6	Finding Information	29
7	Getting Help	31
	Obtaining Assistance	31
	Technical Support and Customer Service	32
	DellConnect™.	32
	Online Services	32
	AutoTech Service	33
	Automated Order-Status Service.	33
	Problems With Your Order	33
	Product Information	34
	Returning Items for Warranty Repair or Credit	34
	Before You Call.	35
	Contacting Dell.	37
	Index	39

About Your Computer

Front View




- 1 power button
- 3 USB 2.0 connectors (2)
- 5 headphone connector

- 2 side cover
- 4 stand
- 6 microphone connector

- | | | | |
|---|--|----|----------------------------|
| 7 | diagnostic lights (see your <i>Service Manual</i> for information about light codes) | 8 | Wi-Fi indicator |
| 9 | hard drive indicator | 10 | network activity indicator |

Back View



- | | | | |
|---|-----------------------------|---|-------------------------|
| 1 | wireless antenna (optional) | 2 | serial connector |
| 3 | DVI connector | 4 | VGA connector |
| 5 | USB 2.0 connectors (4) | 6 | PS/2 keyboard connector |
| 7 | power connector | 8 | PS/2 mouse connector |
| 9 | network connector (RJ-45) | | |

Setting Up Your Computer

Before Setting Up Your Computer

When positioning your computer, ensure that you allow easy access to a power source, adequate ventilation, and a level surface on which to place your computer.



NOTICE: Keep the computer on the stand and in the vertical position. Setting up the computer horizontally (on its side) restricts airflow and can impact performance.

Restricting airflow around the computer may cause it to overheat. To prevent overheating ensure that you leave at least 10.2 cm (4 in) at the back of the computer and a minimum of 5.1 cm (2 in) on all other sides. You should never put your computer in an enclosed space, such as a cabinet or drawer when it is powered on.

Quick Setup




CAUTION: Before you begin any of the procedures in this section, follow the safety instructions that shipped with your computer.




NOTE: Some devices may not be included if you did not order them.


- 1 Connect the monitor using either the white DVI cable or the blue VGA cable.




- 2 Connect a USB device, such as a keyboard or mouse.




- 3** Connect the network cable.



- 4** Connect the power cable.



- 5** Press the power buttons on the monitor and the computer.



Specifications



NOTE: Offerings may vary by region. For more information regarding the configuration of your computer, click **Start→Help and Support** and select the option to view information about your computer.

Processor

Processor type	Intel® Atom™ 200 Series Single-Core processor or Intel Atom 300 Series Dual-Core processor
Level 2 (L2) cache	at least 512 KB pipelined-burst per core, eight-way set associative, writeback SRAM

System Information

Chipset	SiS M671 and SiS 968
DMA channels	seven
Interrupt levels	24
BIOS chip (ROM)	8 Mb
NIC	integrated network interface capable of 10/100/1000 Mbps communication

Memory

Type	667-MHz or 800-MHz DDR2 SDRAM NOTE: When 800 MHz memory is installed, the computer still operates at 667 MHz.
Memory connectors	two DIMMs
Memory capacities	512 MB, 1 GB, and 2 GB modules (512 MB modules supported on Linux)

Memory <i>(continued)</i>	
Minimum memory	1 GB (512 MB for Linux)
Maximum memory	4 GB
Video	
Type:	
SiS Mirage integrated video	default 128 MB shared video memory (can be changed in BIOS system setup)
Audio	
Type:	
ADI 1984A Integrated HD Audio	
Drives	
Internally accessible	one 2.5-in drive bay
Available devices	one 2.5-in SATA hard drive
	NOTE: A hard drive is optional and requires a hard drive kit.
	one NVRAM Flash module (for embedded operating system)
Connectors	
External connectors:	
Video	15-pin VGA connector and 24-pin DVI connector
Network adapter	RJ-45 connector
USB	two front-panel, and four back-panel USB 2.0-compliant connectors
Audio	two jacks (headphone and microphone)
Serial	one 9-pin connector
PS/2	two 6-pin mini-DINs

Connectors *(continued)*

System board connectors:	
Serial ATA (hard drive)	one 7-pin connector
Serial ATA (NVRAM module)	one 22-pin connector
Fan	one 5-pin connector
Mini-PCI Express X1	one 52-pin connector
Front panel LED	one 14-pin connector
Front panel USB	two 10-pin connectors
Front panel audio	one 12-pin connector
Memory	two 240-pin connectors
Power 12 V	one 4-pin connector
BIOS ROM	one 8-pin socket
Serial ATA hard drive power	one 4-pin connector

Controls and Lights

Front of computer:	
Power button	push button
Power light (within the power button)	blue light — Blinking blue in sleep state; solid blue for power on state. amber light — A solid amber light when the computer does not start indicates that the system board cannot start initialization. This could be a system board or a power supply problem (see "Power Problems" on page 17).
Network link light	blue light - A solid blue light indicates network connectivity.
Wireless light	blue light - A solid blue light indicates the wireless network is powered on.
Diagnostic lights (1-4)	See your <i>Service Manual</i> for information about diagnostic light codes.

Controls and Lights <i>(continued)</i>	
Drive activity light	blue light — A blinking blue light indicates the computer is reading data from or writing data to the SATA hard drive.
Rear of computer:	
Link integrity light (on network adapter connector)	green light — 10-Mb operation orange light — 100-MB operation yellow light — 1-Gb operation off (no light) — The computer is not detecting a physical connection to the network.
Network activity light (on network adapter connector)	yellow blinking light
Power	
DC power supply:	
Wattage	50 W
Voltage (see the safety information that shipped with your computer for important voltage setting information)	100-240 V, ~0.8 A, 50-60 Hz
Coin-cell battery	3-V CR2032 lithium coin cell
Physical	
Height	22.9 cm (9.02 in) without stand 26.9 cm (10.6 in) with stand
Width	5.4 cm (2.13 in) with side cover 4.7 cm (1.85 in) without side cover
Depth	25.2 cm (9.92 in)
Weight	1.81–2.09 kg(4.0–4.6 lb) NOTE: Weight varies, depending on configuration and if the stand is included.

Environmental	
Temperature:	
Operating	10° to 35° C (50° to 95° F)
Storage	–40° to 65° C (–40° to 149° F)
Relative humidity	20% to 80% (noncondensing)
Maximum vibration:	
Operating	5 to 350 Hz at 0.0002 G ² /Hz
Storage	5 to 500 Hz at 0.001 to 0.01 G ² /Hz
Maximum shock:	
Operating	40 G +/- 5% with pulse duration of 2 msec +/- 10% (equivalent to 20 in/sec [51 cm/sec])
Storage	105 G +/- 5% with pulse duration of 2 msec +/- 10% (equivalent to 50 in/sec [127 cm/sec])
Altitude:	
Operating	–15.2 to 3048 m (–50 to 10,000 ft)
Storage	–15.2 to 10,668 m (–50 to 35,000 ft)
Airborne contaminant level	G2 or lower as defined by ISA-S71.04-1985

Troubleshooting Tips




CAUTION: Always unplug your computer from the electrical outlet before opening the cover.



NOTE: For detailed troubleshooting information, including responding to system messages, see your *Service Manual* at support.dell.com.

Using the Hardware Troubleshooter

- 1 Click **Start** (Microsoft® Windows® XP embedded) or the Windows Vista® Start button , and click **Help and Support**.
- 2 Type `hardware troubleshooter` in the search field and press <Enter> to start the search.
- 3 In the search results, select the option that best describes your problem and follow the remaining troubleshooting steps.

Tips

- If a device does not work, ensure that the device is properly connected.
- Check the diagnostics lights on the front of the computer or listen for beep codes that may indicate a problem. See your *Service Manual* for more information.
- If you added or removed a part before the problem started, review the installation procedures and ensure that the part is correctly installed.
- If an error message appears on the screen, write down the exact message. This message may help support personnel to diagnose and fix the problem(s).
- If an error message occurs in a program, see the program documentation.

Power Problems



CAUTION: Before working inside your computer, read the safety information that shipped with your computer. For additional safety best practices information, see www.dell.com/regulatory_compliance.

IF THE POWER LIGHT IS OFF — The computer is either turned off or is not receiving power.

- Reseat the power cable in the power connector on the back of the computer and the electrical outlet.
- Bypass power strips, power extension cables, and other power protection devices to verify that the computer turns on properly.
- Ensure that any power strips being used are plugged into an electrical outlet and are turned on.
- Ensure that the electrical outlet is working by testing it with another device, such as a lamp.

IF THE POWER LIGHT IS BLUE AND THE COMPUTER IS NOT RESPONDING —

- Ensure that the display is connected and powered on.
- If the display is connected and powered on, see your *Service Manual* on support.dell.com.

IF THE POWER LIGHT IS BLINKING BLUE — The computer is in standby mode. Press a key on the keyboard, move the mouse, or press the power button to resume normal operation.

IF THE POWER LIGHT IS STEADY AMBER — There is a power problem, or a device may be malfunctioning or incorrectly installed.

ELIMINATE INTERFERENCE — Some possible causes of interference are:

- Power, keyboard, and mouse extension cables
- Too many devices connected to the same power strip
- Multiple power strips connected to the same electrical outlet

Memory Problems



CAUTION: Before working inside your computer, read the safety information that shipped with your computer. For additional safety best practices information, see www.dell.com/regulatory_compliance.

IF YOU RECEIVE AN INSUFFICIENT MEMORY MESSAGE —

- Save and close any open files and exit any open programs you are not using to see if that resolves the problem.
- See the software documentation for minimum memory requirements. If necessary, install additional memory.

- Reseat the memory modules to ensure that your computer is successfully communicating with the memory.
- Run the Dell Diagnostics (see "Dell Diagnostics" on page 21).

IF YOU EXPERIENCE OTHER MEMORY PROBLEMS —

- Reseat the memory modules to ensure that your computer is successfully communicating with the memory.
- Ensure that you are following the memory installation guidelines.
- Ensure that the memory you are using is supported by your computer. For more information about the type of memory supported by your computer, see "Specifications" on page 11.
- Run the Dell Diagnostics (see "Dell Diagnostics" on page 21).

Lockups and Software Problems



NOTE: The procedures in this document were written for the Windows default view and may not apply if you set your Dell computer to the Windows Classic view.

The computer does not start up

ENSURE THAT THE POWER CABLE IS FIRMLY CONNECTED TO THE COMPUTER AND TO THE ELECTRICAL OUTLET

A program stops responding

END THE PROGRAM —

- 1 Press <Ctrl><Shift><Esc> simultaneously to access the Task Manager, and click the **Applications** tab.
- 2 Click to select the program that is no longer responding, and click **End Task**.

A program crashes repeatedly




NOTE: Most software includes installation instructions in its documentation or on a floppy disk, CD, or DVD.

CHECK THE SOFTWARE DOCUMENTATION — If necessary, uninstall and then reinstall the program.

A program is designed for an earlier Microsoft Windows operating system

RUN THE PROGRAM COMPATIBILITY WIZARD —

- 1 Click Start →Control Panel→Programs→Use an older program with this version of Windows.
- 2 In the welcome screen, click Next.
- 3 Follow the instructions on the screen.

A solid blue screen appears

TURN THE COMPUTER OFF — If you are unable to get a response by pressing a key on your keyboard or moving your mouse, press and hold the power button for at least 6 seconds (until the computer turns off), and then restart your computer.

Other software problems

CHECK THE SOFTWARE DOCUMENTATION OR CONTACT THE SOFTWARE MANUFACTURER FOR TROUBLESHOOTING INFORMATION —

- Ensure that the program is compatible with the operating system installed on your computer.
- Ensure that your computer meets the minimum hardware requirements needed to run the software. See the software documentation for information.
- Ensure that the program is installed and configured properly.
- Verify that the device drivers do not conflict with the program.
- If necessary, uninstall and then reinstall the program.


Dell Technical Update Service

The Dell Technical Update service provides proactive e-mail notification of software and hardware updates for your computer. To enroll for the Dell Technical Update service, go to support.dell.com/technicalupdate.


Dell Support Utility



NOTE: The Dell Support Utility is not supported on Linux or Windows XP embedded operating systems.

The Dell Support Utility provides self-support information, software updates, and health scans of your computing environment. Access the Dell Support Utility from the  icon on the taskbar, or from the **Start** menu.

If the Dell Support icon does not appear in your taskbar:

- 1 Click **Start**  → **All Programs** → **Dell Support** → **Dell Support Settings**.
- 2 Ensure that the **Show icon on the taskbar** option is checked.



NOTE: If the Dell Support Utility is not available from the **Start** menu, go to support.dell.com and download the software.

For more information about the Dell Support Utility, click the question mark (?) at the top of the **Dell Support** screen.

Dell Diagnostics



NOTE: Dell Diagnostics is supported only on operating systems installed on the hard drive and Windows XP Embedded running on an NVRAM Flash module.

Starting the Dell Diagnostics (installed on the computer)

- 1 Ensure that the computer is connected to a working electrical outlet.
- 2 Turn on (or restart) your computer.
- 3 When the DELL logo appears, press <F12> immediately. Select **Boot to Utility Partition** and press <Enter>.



NOTE: If you wait too long and the operating system logo appears, continue to wait until you see the Microsoft Windows desktop, and then shut down your computer and try again.



NOTE: If you see a message stating that no diagnostics utility partition has been found, run the Dell Diagnostics from the *Drivers and Utilities* media.

- 4 Press any key to start the Dell Diagnostics from the diagnostics utility partition on your hard drive, and follow the instructions on the screen.

Starting the Dell Diagnostics From the Dell *Drivers and Utilities* Media



NOTE: The Dell *Drivers and Utilities* media is optional and may not ship with your computer. This procedure also requires an external optical drive.

- 1 Connect an external optical drive to the computer.
- 2 Insert the *Drivers and Utilities* media.

- 3 Shut down and restart the computer.

When the DELL logo appears, press <F12> immediately.



NOTE: If you wait too long and the operating system logo appears, continue to wait until you see the Microsoft Windows desktop; then, shut down your computer and try again.



NOTE: The next steps change the boot sequence for one time only. On the next start up, the computer starts according to the devices specified in the system setup program.


- 4 When the boot device list appears, highlight **CD/DVD/CD-RW** and press <Enter>.
- 5 Select **Boot from CD-ROM** from the menu that appears and press <Enter>.
- 6 Type 1 to start the CD menu and press <Enter> to proceed.
- 7 Select **Run the 32 Bit Dell Diagnostics** from the numbered list. If multiple versions are listed, select the version that is appropriate for your computer.
- 8 When the Dell Diagnostics **Main Menu** appears, select the test that you want to run, and follow the instructions on the screen.

Reinstalling Software

Drivers

Identifying Drivers

Windows Vista®

- 1 Locate the list of devices for your computer:
 - a Click the Windows Vista Start button , and right-click **Computer**.
 - b Click **Properties**→**Device Manager**.



NOTE: The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue.

- 2 Scroll down the list to see if any device has an exclamation point (a yellow circle with a [!]) on the device icon.

If an exclamation point is next to the device name, you may need to reinstall the driver or install a new driver (see "Reinstalling Drivers and Utilities" on page 24).

Windows® XP Embedded

- 1 Locate the list of devices for your computer:
 - a Right-click **My Computer** on the desktop.
 - b Click **Properties**.



NOTE: The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue.

- c Click the **Hardware** tab, and then click **Device Manager**.

- 2 Scroll down the list to see if any device has an exclamation point (a yellow circle with a [!]) on the device icon.

If an exclamation point is next to the device name, you may need to reinstall the driver or install a new driver (see "Reinstalling Drivers and Utilities" on page 24).



Reinstalling Drivers and Utilities



NOTICE: The Dell Support website at support.dell.com provides approved drivers for your computer. If you install drivers obtained from other sources, your computer might not work correctly.


Returning to a Previous Device Driver Version

Windows Vista

- 1 Click the Windows Vista Start button , and right-click **Computer**.
- 2 Click **Properties**→**Device Manager**.
 **NOTE:** The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to enter the Device Manager.
- 3 Right-click the device for which the new driver was installed and click **Properties**.
- 4 Click the **Drivers** tab→**Roll Back Driver**.

If Device Driver Rollback does not resolve the problem, use System Restore (see "Restoring Your Operating System" on page 26) to return your computer to the operating state that existed before you installed the new driver.

Windows XP Embedded



- 1 Locate the list of devices for your computer:
 - a Right-click **My Computer** on the desktop.
 - b Click **Properties**.
 **NOTE:** The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue.
- c Click the **Hardware** tab, and then click **Device Manager**.

- 2 Right-click the device for which the new driver was installed and click **Properties**.
- 3 Click the **Drivers** tab→**Roll Back Driver**.


If Device Driver Rollback does not resolve the problem, use System Restore (see "Restoring Your Operating System" on page 26) to return your computer to the operating state that existed before you installed the new driver.

Manually Reinstalling Drivers

Windows Vista

- 1 Click the Windows Vista Start button , and right-click **Computer**.
- 2 Click **Properties**→**Device Manager**.
 **NOTE:** The **User Account Control** window appears. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue.
- 3 Double-click the type of device for which you are installing the driver (for example, **Audio** or **Video**).
- 4 Double-click the name of the device for which you are installing the driver.
- 5 Click the **Driver** tab→**Update Driver**→**Browse my computer for driver software**.
- 6 Click **Browse** and browse to the location to which you previously copied the driver files.
- 7 Click the name of the driver→**OK**→**Next**.
- 8 Click **Finish** and restart your computer.

Windows XP Embedded

- 1 Locate the list of devices for your computer:
 - a Right-click **My Computer** on the desktop.
 - b Click **Properties**.
 **NOTE:** The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue.
 - c Click the **Hardware** tab, and then click **Device Manager**.

- 2 Right-click the device for which you need a driver, and click **Update Driver**.
- 3 Click the **Drivers** tab→**Update Driver**.
- 4 Follow the instructions that appear on the screen to either install the driver from a local source, or to search the Web for a driver.

Restoring Your Operating System

Depending on your system configuration, you can restore your operating system in the following ways:


- Microsoft® Windows System Restore (available only on computers that have hard drives and are running Windows Vista) returns your computer to an earlier operating state without affecting data files. Use System Restore as the first solution for restoring your operating system and preserving data files.
- If you received the *Operating System* media with your computer, you can use it to restore your operating system. However, using the *Operating System* media deletes all data on the hard drive. This option — available only on computers with hard drives with Windows Vista — also requires an external optical drive to run the media.

Using Microsoft Windows System Restore (Windows Vista hard drive operating systems only)



NOTE: The procedures in this document were written for the Windows default view and may not apply if you set your Dell computer to the Windows Classic view.

Starting System Restore

- 1 Click the Windows Vista Start button .
- 2 In the Start Search box, type **System Restore** and press <Enter>.




NOTE: The **User Account Control** window may appear. If you are an administrator on the computer, click **Continue**; otherwise, contact your administrator to continue the desired action.

- 3 Click **Next** and follow the remaining prompts on the screen.

Undoing the Last System Restore



NOTICE: Before you undo the last system restore, save and close all open files and exit any open programs. Do not alter, open, or delete any files or programs until the system restoration is complete.

- 1 Click the Windows Vista Start button .
- 2 In the **Start Search** box, type **System Restore** and press <Enter>.
- 3 Click **Undo my last restoration** and click **Next**.

Finding Information



NOTE: Some features or media may be optional and may not ship with your computer. Some features or media may not be available in certain countries.



NOTE: Additional information may ship with your computer.

Document/Media/Label	Contents
Service Tag/Express Service Code The Service Tag/Express Service Code is located on your computer.	<ul style="list-style-type: none"> • Use the Service Tag to identify your computer when you use support.dell.com or contact support. • Enter the Express Service Code to direct your call when contacting support
Safety, Regulatory, Warranty, and Support Documentation This type of information may have shipped with your computer. For additional regulatory information, see the Regulatory Compliance Homepage on www.dell.com at the following location: www.dell.com/regulatory_compliance .	<ul style="list-style-type: none"> • Warranty information • Terms and Conditions (U.S. only) • Safety instructions • Regulatory information • Ergonomics information • End User License Agreement
Dell Technology Guide The <i>Dell Technology Guide</i> is available at support.dell.com .	<ul style="list-style-type: none"> • About your operating system • Using and maintaining devices • Understanding technologies such as RAID, the Internet, Bluetooth® wireless technology, e-mail, networking, and more.
Microsoft® Windows® License Label Your Microsoft Windows License is located on your computer.	<ul style="list-style-type: none"> • Provides your operating system product key.

Getting Help

Obtaining Assistance



CAUTION: If you need to remove the computer cover, first disconnect the computer power and modem cables from all electrical outlets. Follow the safety instructions that shipped with your computer.

If you experience a problem with your computer, you can complete the following steps to diagnose and troubleshoot the problem:

- 1 See "Tips" on page 17 for information and procedures that pertain to the problem your computer is experiencing.
- 2 See "Dell Diagnostics" on page 21 for procedures on how to run Dell Diagnostics.
- 3 Fill out the "Diagnostics Checklist" on page 36.
- 4 Use Dell's extensive suite of online services available at Dell Support (support.dell.com) for help with installation and troubleshooting procedures. See "Online Services" on page 32 for a more extensive list of Dell Support online.
- 5 If the preceding steps have not resolved the problem, see "Contacting Dell" on page 37.



NOTE: Call Dell Support from a telephone at or near the affected computer so that the support staff can assist you with any necessary procedures.



NOTE: Dell's Express Service Code system may not be available in all countries.

When prompted by Dell's automated telephone system, enter your Express Service Code to route the call directly to the proper support personnel. If you do not have an Express Service Code, open the **Dell Accessories** folder, double-click the **Express Service Code** icon, and follow the directions.

For instructions on using the Dell Support, see "Technical Support and Customer Service" on page 32.



NOTE: Some of the following services are not always available in all locations outside the continental U.S. Call your local Dell representative for information on availability.

Technical Support and Customer Service

Dell's support service is available to answer your questions about Dell hardware. Our support staff uses computer-based diagnostics to provide fast, accurate answers.

To contact Dell's support service, see "Before You Call" on page 35, and then see the contact information for your region or go to support.dell.com.

DellConnect™

DellConnect is a simple online access tool that allows a Dell service and support associate to access your computer through a broadband connection, diagnose your problem and repair it all under your supervision. For more information, go to support.dell.com and click **DellConnect**.

Online Services

You can learn about Dell products and services at the following websites:

www.dell.com

www.dell.com/ap (Asian/Pacific countries only)

www.dell.com/jp (Japan only)

www.euro.dell.com (Europe only)

www.dell.com/la (Latin American and Caribbean countries)

www.dell.ca (Canada only)

You can access Dell Support through the following websites and e-mail addresses:

- Dell Support websites:
support.dell.com
support.jp.dell.com (Japan only)
support.euro.dell.com (Europe only)

- Dell Support e-mail addresses:
mobile_support@us.dell.com
support@us.dell.com
la-techsupport@dell.com (Latin America and Caribbean countries only)
apsupport@dell.com (Asian/Pacific countries only)
- Dell Marketing and Sales e-mail addresses:
apmarketing@dell.com (Asian/Pacific countries only)
sales_canada@dell.com (Canada only)
- Anonymous file transfer protocol (FTP):
ftp.dell.com – log in as user **anonymous**, and use your e-mail address as your password

AutoTech Service

Dell's automated support service—AutoTech—provides recorded answers to the questions most frequently asked by Dell customers about their laptop and desktop computers.

When you call AutoTech, use your touch-tone telephone to select the subjects that correspond to your questions. For the telephone number to call for your region, see "Contacting Dell" on page 37.

Automated Order-Status Service

To check on the status of any Dell products that you have ordered, you can go to **support.dell.com**, or you can call the automated order status service. A recording prompts you for the information needed to locate and report on your order. For the telephone number to call for your region, see "Contacting Dell" on page 37.

Problems With Your Order

If you have a problem with your order, such as missing parts, wrong parts, or incorrect billing, contact Dell for customer assistance. Have your invoice or packing slip available when you call. For the telephone number to call for your region, see "Contacting Dell" on page 37.

Product Information

If you need information about additional products available from Dell, or if you would like to place an order, visit the Dell website at www.dell.com. For the telephone number to call for your region or to speak to a sales specialist, see "Contacting Dell" on page 37.

Returning Items for Warranty Repair or Credit

Prepare all items being returned, whether for repair or credit, as follows:

- 1 Call Dell to obtain a Return Material Authorization Number, and write it clearly and prominently on the outside of the box.

For the telephone number to call for your region, see "Contacting Dell" on page 37. Include a copy of the invoice and a letter describing the reason for the return.

- 2 Include a copy of the Diagnostics Checklist (see "Diagnostics Checklist" on page 36), indicating the tests that you have run and any error messages reported by the Dell Diagnostics (see "Contacting Dell" on page 37).
- 3 Include any accessories that belong with the item(s) being returned (power cables, software floppy disks, guides, and so on) if the return is for credit.
- 4 Pack the equipment to be returned in the original (or equivalent) packing materials.

You are responsible for paying shipping expenses. You are also responsible for insuring any product returned, and you assume the risk of loss during shipment to Dell. Collect On Delivery (C.O.D.) packages are not accepted.

Returns that are missing any of the preceding requirements will be refused at Dell's receiving dock and returned to you.

Before You Call



NOTE: Have your Express Service Code ready when you call. The code helps Dell's automated support telephone system direct your call more efficiently. You may also be asked for your Service Tag (located on the back or bottom of your computer).

Remember to fill out the Diagnostics Checklist (see "Diagnostics Checklist" on page 36). If possible, turn on your computer before you call Dell for assistance and call from a telephone at or near the computer. You may be asked to type some commands at the keyboard, relay detailed information during operations, or try other troubleshooting steps possible only at the computer itself. Ensure that the computer documentation is available.



CAUTION: Before working inside your computer, follow the safety instructions in the documentation that shipped with your computer.

Diagnostics Checklist

Name:

Date:

Address:

Phone number:

Service Tag (bar code on the back or bottom of the computer):

Express Service Code:

Return Material Authorization Number (if provided by Dell support technician):

Operating system and version:

Devices:

Expansion cards:

Are you connected to a network? Yes No

Network, version, and network adapter:

Programs and versions:

See your operating system documentation to determine the contents of the system's start-up files. If the computer is connected to a printer, print each file. Otherwise, record the contents of each file before calling Dell.

Error message, beep code, or diagnostic code:

Description of problem and troubleshooting procedures you performed:

Contacting Dell

For customers in the United States, call 800-WWW-DELL (800-999-3355).



NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

- 1 Visit **support.dell.com**, and verify your country or region in the **Choose A Country/Region** drop down menu at the bottom of the page.
- 2 Click **Contact Us** on the left side of the page, and select the appropriate service or support link based on your need.
- 3 Choose the method of contacting Dell that is convenient for you.

Index

C

- connecting
 - monitor, 8
 - network cable, 9
 - power cables, 9
- contacting Dell, 31, 37

D

- Dell
 - contacting, 31, 37
 - software updates, 20
 - Support Utility, 20
 - technical support and customer service, 32
 - Technical Update Service, 20
- Dell Diagnostics, 21
 - starting from the Drivers and Utilities media, 21
 - starting from your hard drive, 21
- Dell Technology Guide, 29
- DellConnect, 32
- diagnostics
 - Dell, 21
- documentation, 29
 - Dell Technology Guide, 29
 - Service Manual, 29

- drivers, 23
 - identifying, 23
 - reinstalling, 24
 - returning to a previous version, 24
- Drivers and Utilities media
 - Dell Diagnostics, 21

E

- End User License Agreement (EULA), 29
- ergonomics information, 29
- Express Service Code, 29

F

- finding information, 29

L

- license label, 29

M

- memory
 - troubleshooting, 18

O

- operating system
 - System Restore, 26
- operating system product key, 29

P

- phone numbers, 37
- power
 - power light conditions, 17
 - troubleshooting, 17
- problems
 - restore to previous state, 26

R

- regulatory information, 29
- reinstalling
 - drivers and utilities, 24
 - software, 23

S

- safety information, 29
- Service Manual, 29
- Service Tag, 29
- setup
 - computer, 7
- software
 - problems, 20
 - reinstalling, 23

- software (*continued*)
 - troubleshooting, 19-20
 - updates, 20

- specifications
 - all, 11
 - audio, 12
 - connectors, 12
 - controls and lights, 13
 - drives, 12
 - environmental, 15
 - memory, 11
 - physical, 14
 - power, 14
 - processor, 11
 - system information, 11
 - video, 12

- support, 31
 - contacting Dell, 37
 - DellConnect, 32
 - online services, 32
 - regional, 32
 - technical support and customer service, 32

- support information, 29

- System Restore, 26

T

- Terms and Conditions, 29
- troubleshooting, 17
 - blue screen, 20
 - computer not responding, 19

troubleshooting (*continued*)

- Dell Diagnostics, 21
- memory, 18
- power, 17
- power light conditions, 17
- program crashes, 19
- programs and Windows
 - compatibility, 20
- restore to previous state, 26
- software, 19-20
- tips, 17

U

- updates
 - software and hardware, 20

V

- view
 - back, 6
 - front, 5

W

- warranty information, 29
- Windows License label, 29
- Windows Vista
 - Device Driver Rollback, 24
 - Program Compatibility wizard, 20
 - returning to a previous device
 - driver version, 24
 - System Restore, 26
- Windows XP
 - System Restore, 26
- wizards
 - Program Compatibility wizard, 20

